ethod



ly, press the
ontrol button

Jog mode

Press the code matching button on the control board once, a
LED indicator light will flash once. After the LED indicator ligh
press the remote control button that needs to match the cod
control board LED indicator light will flash continuously for th
times and the code matching is successful.

Clear code metho

Press the control board code matching button 8 times in a row, a
the LED indicator light will flash 8 times. At this time, the LED ind
light will automatically flash 3 times continuously and turn off,
indicating that the code cleaning is completed.
(After clearing the storage code of the receiver, all previously ma
remote controls and receivers cannot be used together.)